



Steps:

1. First, make sure that all circuit breakers are disconnected.
2. Connect the AC Grid input line, photovoltaic line, AC output line, battery connection line, and parallel communication line of the inverter in sequence as shown in the figure, and connect firmly.

Note:

Each inverter needs to be separately equipped with photovoltaic panels;

The input and output L and N of each inverter must be in the same phase and cannot be crossed;

The battery input terminals of each inverter must be connected in parallel;

The parallel communication connection must be ensured before powering on.

3. Close the battery connection circuit breakers of the two inverters in sequence.
4. Close the photovoltaic panel connection circuit breakers of the two inverters in sequence.
5. Close the mains input circuit breakers of the two inverters in sequence.
6. Close the output circuit breakers of the two inverters in sequence.
7. Turn on the ON/OFF switches of the two inverters in turn.
8. Check the working status of the two inverters in turn to see if the display is normal. If there is no abnormality, close the main parallel circuit breakers.

The machine is loaded normally and the operation is complete.